



Spectra SP440 Double Entry Screen

INSTALLATION INSTRUCTIONS

Issue 2 - November 2008

**We recommend the shower tray is fitted correctly and sealed, prior to tiling.
Tile down onto the tray and re-seal before installing shower enclosure.**

Spectra SP440 Double Entry Screen

INSTALLATION INSTRUCTIONS

TWO MAN INSTALLATION

Ensure that shower enclosure area is tiled prior to installing the shower enclosure

Equipment Required For Installation

Power drill, 6mm masonry drill bit, tape measure, ruler, pencil, masking tape, sanitary grade silicone sealant, rubber mallet, posidrive screwdriver / bits, spirit level and the fitting kit supplied which includes wall plugs, screws, plastic tube and allen keys.

The components for the Spectra Shower Screen are packed in one box comprising:-

- a) Straight glass screen
- b) Wall Fixing brackets and brace(s)
- c) Fitting Kit
- d) Installation Instructions and
- e) Squeegee.

Please open boxes with care and notify your supplier immediately if anything is damaged. Please do not discard packaging. Repack carefully if necessary.

- For wet room applications ensure the area is professionally sealed and flat where the screen meets the floor or walls. If fitting onto a shower tray follow manufacturer's installation instructions. Ensure the tray is level using a spirit level on at least two diagonals. Check the tray has been sealed correctly and sealant is cured before attempting to install the shower enclosure. We recommend sealing the tray prior to tiling, tiling down onto tray and re-sealing. The floor area around the tray should also be sealed and waterproof.
- Position chrome blocks 12.5mm in from the top edge of the shower screen at both ends.
- Mark out positions for the wall sockets as indicated in the diagram. The vertical dimension is 1962mm above the tray/ wet room floor aligned with the centres of the screen blocks. The tray /screen size determines the centres for the width between the wall sockets. Ensure the sockets are central about the tray. Using masking tape to mark onto the tiled surface drill the wall and use the wall plugs provided. Make sure they are flush and screw the wall sockets into position.
- Cut the steady bars provided to the required length which is calculated by measuring wall to the shower screen position + 12mm. Make allowance for out of true walls.
- Position the screen aligning parallel to the wall on the tray rim and engage the steady bar into two steady blocks on the top edge of the glass. Tighten the grub screws in the top of the steady blocks and the wall sockets. Check for vertical and adjust as necessary.
- Apply a continuous small bead of silicone caulking to the inside and outside edge of the screen. Ensure a good seal is made and there are no pin holes in the sealant.

DO NOT USE THE SHOWER ENCLOSURE FOR 24 HOURS TO ENSURE SILICONE IS FULLY CURED AND WATERPROOF.

